



4 Wheel Walker

Purpose

To provide support and stability whilst walking and a place to rest as required

Features

- Removable backrest and basket are included
- Flip-up padded seat
- Lightweight aluminium frame
- Easy folding for storage and transport
- Hand brakes (either push down or bicycle style)
- Suitable for both indoor/outdoor use

Installation

- Adjust handles to the appropriate height by unscrewing the adjustment bolt on each handle and sliding the handles up or down. The height should ideally be set by your therapist, but as a guide you should be standing upright with you elbows slightly bent.

Maintenance

- The 4 wheel walker should be checked monthly for signs of rust, cracks, break performance and wheel wear and tear. If any of these are present, stop use and contact your supplier.

- This product should be cleaned regularly with warm soapy water unless otherwise stated by the manufacturer.

Safety and precautions

- Use two hands when using the 4 wheel walker to avoid tipping.
- Ensure brakes are locked on before sitting on the seat.
- Do not stand on this equipment.
- You should only use the equipment in the environment in which it is prescribed.
- It is not recommended for use by other people.
- 100kg weight limit unless otherwise stated by the manufacturer.
- Ensure the silver buttons on the height adjustable handles have slotted into the correct holes before using.

Your therapist has recommended the appropriate height for your 4 wheel walker as:

.....

Other comments

.....

All information contained in this sheet is a guideline for care only, supplied by qualified health professionals. Acknowledgements to Toowoomba Health Service District, Queensland Health and Gold Coast Health Service District

Contact Us.

P 1800 684 277

E info@maxhealth.com.au

W maxhealthcareequipment.com.au